

# MedEco ICB C1

Technical DataSheet | Supplied by BIOVOX

MedEco ICB C1 by BIOVOX is a bio-based, medical grade thermoplastic. It is recommended for highly transparent injection molded components.

- It exhibits high- rigidity, strength, stiffness and surface hardness.
- It offers very good shape filling and easy processing at low temperatures, saving energy.
- It is recyclable, biodegradable and resilient with the smallest carbon footprint.
- MedEco ICB C1 is suitable for wellplates, surgical instruments, and intravenous access systems.

Product Type	Unspecified Thermoplastic > Unspecified Thermoplastic, Bio-based
Product Status	COMMERCIAL
Applications/ Recommended for	Healthcare / Medical > Medical goods Healthcare / Medical > Surgery instruments Injection molding - thermoplastics
Biodegradable	Yes
Bio Based	Yes
Bio Based Content (%)	100
Labels/Agency Rating	EN ISO 13432 
Key Features	Biodegradable Energy Saving Hardness, High Processability, Good Recyclable Stiffness, High Strength, High Transparency, High

## MedEco ICB C1 Properties

Physical	Value & Unit	Test Condition	Test Method
Melt Mass-Flow Rate (MFR or MFI = Melt Flow Index or MI = Melt Index)	32 g/10 min	At 190°C, 2.16 kg	ISO 1133-A

Density	1.24 g/cm <sup>3</sup>
---------	------------------------

Linear Mold Shrinkage	0.45 - 0.8 %
-----------------------	--------------

Bio Carbon Content	100 %
--------------------	-------

Thermal	Value & Unit	Test Condition	Test Method
Melting Point	175 °C		ISO 3146
Deflection Temperature at 0.46 MPa (66 psi)	60 °C		ISO 75-1

Mechanical	Value & Unit	Test Condition	Test Method
Tensile Strength	65 N/mm <sup>2</sup>		ISO 527-1/1A
Impact Strength, Notched Izod	2.5 kJ/m <sup>2</sup>	At 23°C	ISO 180
Modulus of Elasticity	3450 N/mm <sup>2</sup>		ISO 527-1/1A
Elongation at Break	2 %		ISO 527-1/1A

MedEco ICB C1 Processing Guidelines

Injection molding	Value & Unit	Test Condition	Test Method
Hopper Temperature	40 °C		
Feeding Zone Temperature	170 °C		

Nozzle Temperature 185 °C

Compression Zone Temperature 180 °C

Measuring Zone Temperature 190 °C

Tool Temperature 30 - 40 °C

Drying Temperature 60 °C

Drying Time > 6 hr

.....

Help us improve the Universal Selector

You can't find what you are looking for? Please report missing products / suppliers, point out errors, or simply tell us how we could make the Universal Selector better.