

ArcBiox™ BGF30–HA

Technical DataSheet | Supplied by ABMcomposite

ArcBiox™ BGF30-HA by ABMcomposite is a high temperature resistant, biodegradable, bio-polyester blend reinforced with long glass fiber. It contains 25% bio-based content. It offers good flowability, high stiffness & strength, excellent flatness & dimensional stability and high temperature resistance. It can be processed by injection molding. ArcBiox™ BGF30-HA is recommended for automotive, consumer electronics and furniture industry.

Product Type Polyester > Polyester, Bio-based

Product Status COMMERCIAL

Applications/ Recommended for
Furnitures
Electronics / Computers
Automotive
Injection molding - thermoplastics

Biodegradable Yes

Bio Based Yes

Bio Based Content (%) 25

Key Features
Biodegradable
Dimensional stability, Good
Filled, Glass Fiber
Flow, Good
Renewable Resource Content
Stiffness, High
Strength, High

ArcBiox™ BGF30–HA Properties

Physical	Value & Unit	Test Condition	Test Method
Density	1.5 g/cm³		ISO 1183 A

Mechanical	Value & Unit	Test Condition	Test Method
Tensile Strength at Break	109 MPa		ISO 527

Flexural Strength	174 MPa	ISO 178
Impact Strength, Izod	40 kJ/m ²	ISO 180/U
Impact Strength, Notched Izod	15 kJ/m ²	ISO 180/A
Flexural Modulus	9.1 GPa	ISO 178

Thermal	Value & Unit	Test Condition	Test Method
Vicat Softening Temperature	202 °C	B 50	ISO 306
Heat Deflection Temperature (HDT)	208 °C	1.8 MPa	ISO 75

ArcBioxTM BGF30–HA Processing Guidelines

Injection Molding	Value & Unit	Test Condition	Test Method
Melt Temperature	250 - 260 °C		
Nozzle Temperature	240 - 260 °C		
Feed Temperature	240 - 250 °C		
Compression Section	250 - 260 °C		
Metering Section	250 - 260 °C		
Holding Pressure	60 %		
Mold Temperature	80 °C		

Feed Throat Temperature 30 - 50 °C

**Drying Temperature,
Dehumidifying Dryer** 80 °C

Screw Speed low - medium

Back Pressure 3 - 5 bar

**Drying Time,
Dehumidifying Dryer** 4 - 5 hr

.....

Help us improve the Universal Selector

You can't find what you are looking for? Please report missing products / suppliers, point out errors, or simply tell us how we could make the Universal Selector better.